
Comfort-Aire®

 **Century**®



REPLACEMENT PARTS LIST

CEILING CASSETTE

B-VHP09CA-1



B-VHP12CA-1

B-VHP18CA-1

B-VHP24CA-1

EXPLODED VIEW

Optional function parts



REPLACEMENT PARTS

Location	Part Name	Quantity	Part No.
2	Ventilation ring assembly	1.0	12122500002031
3	Water collector subassembly	1.0	12822500A00067
3.1	Water level switch	1.0	17400511001244
4	Centrifugal fan	1.0	12100103000149
5	evaporator assembly	1.0	15822500002359
5.1	evaporator outlet pipe subassembly	1.0	15122500003156
5.2	Copper nut	1.0	15500404000005
5.3	evaporator inlet pipe subassembly	1.0	15122500003237
5.4	Pipe temperature sensor subassembly	1.0	11201007003442
5.5	Detection valve	1.0	15500209000002
6	Asynchronous motor	1.0	11002015012268
7	Chassis assembly	1.0	12222500002035
8	evaporator fixing hanger	1.0	12222500000084
9	Pipe fixing board assembly	1.0	12122500002028
10	evaporator fixing board subassembly	1.0	12222500001673
11	Gas sensor	1.0	11201003000344
17	Electronic control box assembly	1.0	17222500004645
17.2	Insulation plate	1.0	12122500002047
17.3	Main control board assembly	1.0	17122500006111
17.4	Terminal block	1.0	17400401006536
17.6	Ambient temperature sensor subassembly	1.0	11201007003424
17.7	Reactor	1.0	17400306000923
17.11	Humidity sensor subassembly	1.0	17122000048868
18	Cover of electronic control box	1.0	12222500002033
19	Remote controller	1.0	17317000012078
22	External water pump box assembly	1.0	12122500003147
23	Water pump assembly	1.0	11001010001757
41	Accessory kit	1.0	12011600005258
46	Copper nut	1.0	15500406000010
46	Copper nut	1.0	15500406000003

Due to ongoing product improvements, specifications and dimensions are subject to change and correction without notice or incurring obligations. Determining the application and suitability for use of any product is the responsibility of the installer. Additionally, the installer is responsible for verifying dimensional data on the actual product prior to beginning any installation preparations.

Incentive and rebate programs have precise requirements as to product performance and certification. All products meet applicable regulations in effect on date of manufacture; however, certifications are not necessarily granted for the life of a product. Therefore, it is the responsibility of the applicant to determine whether a specific model qualifies for these incentive/rebate programs.





1900 Wellworth Ave., Jackson, MI 49203 • Ph. 517-787-2100 • www.marsdelivers.com



EXPLODED VIEW

Optional function parts



REPLACEMENT PARTS

Location	Part Name	Quantity	Part No.
2	Ventilation ring assembly	1.0	12122500002031
3	Water collector subassembly	1.0	12822500A00067
3.1	Water level switch	1.0	17400511001244
4	Centrifugal fan	1.0	12100103000149
5	evaporator assembly	1.0	15822500002359
5.1	evaporator outlet pipe subassembly	1.0	15122500003156
5.2	Copper nut	1.0	15500404000005
5.3	evaporator inlet pipe subassembly	1.0	15122500003237
5.4	Pipe temperature sensor subassembly	1.0	11201007003442
5.5	Detection valve	1.0	15500209000002
6	Asynchronous motor	1.0	11002015012268
7	Chassis assembly	1.0	12222500002035
8	evaporator fixing hanger	1.0	12222500000084
9	Pipe fixing board assembly	1.0	12122500002028
10	evaporator fixing board subassembly	1.0	12222500001673
11	Gas sensor	1.0	11201003000344
17	Electronic control box assembly	1.0	17222500004645
17.2	Insulation plate	1.0	12122500002047
17.3	Main control board assembly	1.0	17122500006111
17.4	Terminal block	1.0	17400401006536
17.6	Ambient temperature sensor subassembly	1.0	11201007003424
17.7	Reactor	1.0	17400306000923
17.11	Humidity sensor subassembly	1.0	17122000048868
18	Cover of electronic control box	1.0	12222500002033
19	Remote controller	1.0	17317000012078
22	External water pump box assembly	1.0	12122500003147
23	Water pump assembly	1.0	11001010001757
41	Accessory kit	1.0	12011600005258
46	Copper nut	1.0	15500406000010
46	Copper nut	1.0	15500406000003

Due to ongoing product improvements, specifications and dimensions are subject to change and correction without notice or incurring obligations. Determining the application and suitability for use of any product is the responsibility of the installer. Additionally, the installer is responsible for verifying dimensional data on the actual product prior to beginning any installation preparations.

Incentive and rebate programs have precise requirements as to product performance and certification. All products meet applicable regulations in effect on date of manufacture; however, certifications are not necessarily granted for the life of a product. Therefore, it is the responsibility of the applicant to determine whether a specific model qualifies for these incentive/rebate programs.





1900 Wellworth Ave., Jackson, MI 49203 • Ph. 517-787-2100 • www.marsdelivers.com



EXPLODED VIEW

Optional function parts



REPLACEMENT PARTS

Location	Part Name	Quantity	Part No.
2	Ventilation ring assembly	1.0	12122500002031
3	Water collector subassembly	1.0	12822500A00067
3.1	Water level switch	1.0	17400511001244
4	Centrifugal fan	1.0	12100103000149
5	evaporator assembly	1.0	15822500002359
5.1	evaporator outlet pipe subassembly	1.0	15122500003156
5.2	Copper nut	1.0	15500404000005
5.3	evaporator inlet pipe subassembly	1.0	15122500003237
5.4	Pipe temperature sensor subassembly	1.0	11201007003442
5.5	Detection valve	1.0	15500209000002
6	Asynchronous motor	1.0	11002015012268
7	Chassis assembly	1.0	12222500002035
8	evaporator fixing hanger	1.0	12222500000084
9	Pipe fixing board assembly	1.0	12122500002028
10	evaporator fixing board subassembly	1.0	12222500001673
11	Gas sensor	1.0	11201003000344
17	Electronic control box assembly	1.0	17222500004645
17.2	Insulation plate	1.0	12122500002047
17.3	Main control board assembly	1.0	17122500006111
17.4	Terminal block	1.0	17400401006536
17.6	Ambient temperature sensor subassembly	1.0	11201007003424
17.7	Reactor	1.0	17400306000923
17.11	Humidity sensor subassembly	1.0	17122000048868
18	Cover of electronic control box	1.0	12222500002033
19	Remote controller	1.0	17317000012078
22	External water pump box assembly	1.0	12122500003147
23	Water pump assembly	1.0	11001010001757
41	Accessory kit	1.0	12011600005258
46	Copper nut	1.0	15500406000010
46	Copper nut	1.0	15500406000003

Due to ongoing product improvements, specifications and dimensions are subject to change and correction without notice or incurring obligations. Determining the application and suitability for use of any product is the responsibility of the installer. Additionally, the installer is responsible for verifying dimensional data on the actual product prior to beginning any installation preparations.

Incentive and rebate programs have precise requirements as to product performance and certification. All products meet applicable regulations in effect on date of manufacture; however, certifications are not necessarily granted for the life of a product. Therefore, it is the responsibility of the applicant to determine whether a specific model qualifies for these incentive/rebate programs.





1900 Wellworth Ave., Jackson, MI 49203 • Ph. 517-787-2100 • www.marsdelivers.com



EXPLODED VIEW

Optional function parts



for some models

for some models

REPLACEMENT PARTS

Location	Part Name	Quantity	Part No.
2	Ventilation ring assembly	1.0	12122500002031
3	Water collector subassembly	1.0	12822500A00067
3.1	Water level switch	1.0	17400511001244
4	Centrifugal fan	1.0	12100103000149
5	evaporator assembly	1.0	15822500002359
5.1	evaporator outlet pipe subassembly	1.0	15122500003156
5.2	Copper nut	1.0	15500404000005
5.3	evaporator inlet pipe subassembly	1.0	15122500003237
5.4	Pipe temperature sensor subassembly	1.0	11201007003442
5.5	Detection valve	1.0	15500209000002
6	Asynchronous motor	1.0	11002015012268
7	Chassis assembly	1.0	12222500002035
8	evaporator fixing hanger	1.0	12222500000084
9	Pipe fixing board assembly	1.0	12122500002028
10	evaporator fixing board subassembly	1.0	12222500001673
11	Gas sensor	1.0	11201003000344
17	Electronic control box assembly	1.0	17222500004645
17.2	Insulation plate	1.0	12122500002047
17.3	Main control board assembly	1.0	17122500006111
17.4	Terminal block	1.0	17400401006536
17.6	Ambient temperature sensor subassembly	1.0	11201007003424
17.7	Reactor	1.0	17400306000923
17.11	Humidity sensor subassembly	1.0	17122000048868
18	Cover of electronic control box	1.0	12222500002033
19	Remote controller	1.0	17317000012078
22	External water pump box assembly	1.0	12122500003147
23	Water pump assembly	1.0	11001010001757
41	Accessory kit	1.0	12011600005258
46	Copper nut	1.0	15500406000010
46	Copper nut	1.0	15500406000003

Due to ongoing product improvements, specifications and dimensions are subject to change and correction without notice or incurring obligations. Determining the application and suitability for use of any product is the responsibility of the installer. Additionally, the installer is responsible for verifying dimensional data on the actual product prior to beginning any installation preparations.

Incentive and rebate programs have precise requirements as to product performance and certification. All products meet applicable regulations in effect on date of manufacture; however, certifications are not necessarily granted for the life of a product. Therefore, it is the responsibility of the applicant to determine whether a specific model qualifies for these incentive/rebate programs.



1900 Wellworth Ave., Jackson, MI 49203 • Ph. 517-787-2100 • www.marsdelivers.com

